
REINFORCING BAR LIST

- ① 100 millimeter Perforated Subdrain (Polyethylene corrugated tubing).
- ② 150 millimeter CMP 0.6 meters long.
- ③ Perforated Subdrain fits into CMP minimum 300 millimeters if grout is used.  
At contractor's option, use reducing coupler or grout.
- ④ Removable mesh cap, 10 millimeter hardware cloth.
- ⑤ Trowel smooth and place subgrade paper to prevent bond.

<b>M</b>	 <b>Iowa Department of Transportation</b> <b>Project Development Division</b>	
	<b>STANDARD ROAD PLAN</b>	<b>RA-48</b>
	REVISION: Metric conversion of Detail Sheet 500-17 no. 2 (dated 4-28-92).	REVISION NO. New
	<i>Daniel L. Leith</i> 11-30-95 APPROVED BY DESIGN METHODS ENGINEER	REVISION DATE 03-26-96
<b>METRIC VERSION</b>	MEDIAN INTAKE ON SUPERELEVATED ROADWAY	